Practical No.: 6 Aim: Create a Mobile Application to 1.Turn on and Turn off Bluetooth 2. Enable and Disable WiFi

Source Code:

Granting permission to Enable, Disable WiFi and Bluetooth

AndroidManifest.xml

```
<uses-permission android:name="android.permission.INTERNET"/>
<uses-permission android:name="android.permission.BLUETOOTH"/>
<uses-permission android:name="android.permission.BLUETOOTH_ADMIN"/>
<uses-permission android:name="android.permission.ACCESS_COARSE_LOCATION"/>
<uses-permission android:name="android.permission.ACCESS_WIFI_STATE"/>
<uses-permission android:name="android.permission.CHANGE_WIFI_STATE"/>
```

```
Activity_main.xml
<?xml version="1.0" encoding="utf-8"?>
<LinearLayout xmlns:android="http://schemas.android.com/apk/res/android"</p>
  xmlns:app="http://schemas.android.com/apk/res-auto"
  xmlns:tools="http://schemas.android.com/tools"
  android:layout_width="match_parent"
  android:layout_height="match_parent"
  android:orientation="vertical"
  tools:context=".MainActivity">
  <Button
    android:layout width="wrap content"
    android:layout_height="wrap_content"
    android:id="@+id/btnOn"
    android:text="@string/turn_on"/>
  <Button
    android:id="@+id/btnOff"
    android:layout_width="match_parent"
    android:layout_height="wrap_content"
    android:text="@string/turn_off"/>
  <Button
    android:id="@+id/btnWifiOn"
    android:layout_width="wrap_content"
    android:layout height="wrap content"
    android:text="@string/wifi_on"/>
  <Button
    android:id="@+id/btnWifiOff"
    android:layout_width="match_parent"
    android:layout_height="wrap_content"
    android:text="@string/wifi_off"/>
</LinearLayout>
```

MainActivity.java

```
package com.example.practical_no_6;
import androidx.appcompat.app.AppCompatActivity;
import android.bluetooth.BluetoothAdapter;
import android.content.Context;
import android.content.Intent;
import android.net.wifi.WifiManager;
import android.os.Bundle;
import android.view.View;
import android.widget.Button;
import android.widget.Toast;
public class MainActivity extends AppCompatActivity {
  Button btnOn,btnOff,btnWifiOn,btnWifiOff;
  WifiManager wifiManager;
  BluetoothAdapter bluetoothAdapter:
  @Override
  protected void onCreate(Bundle savedInstanceState) {
    super.onCreate(savedInstanceState);
    setContentView(R.layout.activity_main);
    btnOn=findViewById(R.id.btnOn);
    btnOff=findViewById(R.id.btnOff);
    btnWifiOn=findViewById(R.id.btnWifiOn);
    btnWifiOff=findViewById(R.id.btnWifiOff);
    wifiManager = (WifiManager)\ getApplicationContext().getSystemService(Context.WIFI\_SERVICE);
    bluetoothAdapter=BluetoothAdapter.getDefaultAdapter();
    btnWifiOn.setOnClickListener(
        new View.OnClickListener() {
           @Override
           public void onClick(View v) {
             wifiManager.setWifiEnabled(true);
             Toast.makeText(MainActivity.this, "WiFi Turned On",
Toast.LENGTH SHORT).show();
           }
    );
    btnWifiOff.setOnClickListener(
        new View.OnClickListener() {
           @Override
           public void onClick(View v) {
             wifiManager.setWifiEnabled(false);
             Toast.makeText(MainActivity.this, "WiFi Turned Off",
Toast.LENGTH_SHORT).show();
           }
         }
    );
```

```
btnOn.setOnClickListener(
        new View.OnClickListener() {
           @Override
           public void onClick(View v) {
             if(bluetoothAdapter==null)
               Toast.makeText(MainActivity.this, "Bluetooth Not Supported",
Toast.LENGTH_SHORT).show();
             }
             else
               if(!bluetoothAdapter.isEnabled())
                 start Activity For Result (new \\
Intent(BluetoothAdapter.ACTION_REQUEST_ENABLE),1);
                 Toast.makeText(MainActivity.this, "Bluetooth Turned On",
Toast.LENGTH_SHORT).show();
             }
    );
    btnWifiOff.setOnClickListener(
        new View.OnClickListener() {
           @Override
           public void onClick(View v) {
             if(bluetoothAdapter!=null)
               bluetoothAdapter.disable();
             Toast.makeText(MainActivity.this, "Bluetooth Turned Off",
Toast.LENGTH_SHORT).show();
    );
  }
Strings.xml
<resources>
  <string name="app_name">Practical_No_6</string>
  <string name="turn_on">Turn On</string>
  <string name="turn_off">Turn Off</string>
  <string name="wifi on">Wifi On</string>
  <string name="wifi_off">Wifi Off</string>
</resources>
```

Output:



